pholc


MANUAL

Dream Catcher Arc & Bow


pholc

ASSEMBLE

1.




2A.




Install the ceiling cup in the ceiling

2B.



Install the ceiling cup to a junction box

3.




Connect the terminal according to the instructions.

4.

On the right you can see some different suggestions.


Feel free to use the template provided for easy installation, or choose your own layout.

5.




Install the five attachment points on the ceiling as shown.

6.




Pull the cables through the ceiling cup & the ring

7.




Insert the cable into the strain relief and secure with the locking screw.

8.




Insert the strain relief and secure with the locking ring.

9.




Connect the three light sources, pay attention to + and -

10.




Mount the ceiling cup cover after installation. Make sure that no cables are pinched.

11.




4. ARC



Install the five attachment points on the ceiling as shown.

4. BOW




Install the five attachment points on the ceiling as shown.

LIGHT CONTROL OPTIONS


Carefully read these instructions before starting the installation and keep them for future reference. The luminaire must be installed by a licensed electrician in compliance with local regulations. Make sure the power is turned off before performing any installation or maintenance.

DALI.




Light control when using a DALI master

PUSH.




Light control using a spring-loaded push button

TRIAC.



Light control when using front and rear edge dimmers

0/1-10V.



Lighting control when using 0-10V or 1-10V control.

pholc

INFORMATION


CE marking


Sort as electrical waste


Class 1


For indoor use



Max effect



Voltage range



Lightsource replaceable by professional


Driver replaceable by professional


Dimmable by TRIAC



Dimmable by DALI



Dimmable by PUSH



Dimmable by 0/1-10V

CLEANING

Wipe with a dry cloth. Never use detergents containing abrasives or solvents.

ENERGY CLASS

The luminaire contains light sources with energy class G in Regulation (EU) No 2019/2015.

NAME	TYPE	ITEM NO
Dream Catcher Bow	Pendant lamp	214 133
Dream Catcher Arc	Pendant lamp	214 134

Version 1

pholc

EN: CAUTION

DISCONNECT POWER

Always shut off power at the circuit breaker or disconnect fuse when installing or repairing this or any other electric appliance. Failure to do so may result in severe injury.

If the external flexible cable or cord of this lamp is damaged, it shall be exclusively replaced by the manufacturer, the service agent or a similar qualified person in order to avoid a hazard.

SV: VARNING

BRYT STRÖMMEN

Se till att lampan är spänningslös innan installationen påbörjas. Underlåtenhet att göra detta kan leda till allvarlig personskada.

Om sladden eller någon kabel till lampan är skadad får utbyte av delar endast utföras av person med rätt kvalifikationer för att undvika att man utsätter sig för fara.

DE: VORSICHT

TRENNEN SIE DIE STROMVERSORGUNG

Schalten sie die stromversorgung aus stellen sie sicher, dass die lampe stromlos ist, bevor sie mit der installation beginnen. Andernfalls kann es zu schweren verletzungen kommen.

Wenn das externe flexible kabel dieser leuchte beschädigt wird, wenden sie sich ausschließlich an den hersteller, seinen kundendienst oder eine ähnlich qualifizierte person, um eine gefährdung zu vermeiden.

FI: VAROITUS

KATKAISE VIRTA

Ennen asennusta varmista ettei valaisimessa ole virtaa. Jos näin ei tehdä seurauksena voi olla vakavia vammoja.

Jos jokin valaisimeen kytketyistä johdoista on vahingoittunut, niin vaaran välttämiseksi vahingoittuneiden osien vaihdon saa suorittaa ainoastaan vaadittavan pätevyyden omaava henkilö.

FR: MISE EN GARDE

DÉCONNECTER L'ALIMENTATION

Coupez toujours l'alimentation au disjoncteur ou débranchez le fusible lors de l'installation ou de la réparation de cet appareil ou de tout autre appareil électrique. Ne pas le faire peut entraîner de graves blessures.

Si le câble de ce luminaire est endommagé, il doit être remplacé exclusivement par le fabricant ou par une personne qualifiée afin d'éviter tout incident.

ES: PRECAUCIÓN

DESCONECTE LA ENERGÍA

Siempre corte la energía en el disyuntor o desconecte el fusible al instalar o reparar este o cualquier otro aparato eléctrico. No hacerlo puede resultar en lesiones graves.

Si el cable exterior flexible o el cordón de esta luminaria está dañado, debe ser sustituido exclusivamente por el fabricante o en su defecto por su servicio técnico o por un profesional cualificado similar para evitar posibles riesgos.

Mogölsvägen 6, 554 75 Jönköping, Sweden, pholc.se